


WORLD CCTV


MANUAL

1. Plug IP camera/DVR/NVR to the router by ethernet cable.
2. Get a windows computer that is connected to the same router. Install software. Here is the software download link. <https://cctv-world.space/wp-content/s/hik/SADPTool.exe>
3. Run the software and it will detect the camera IP or NVR/DVR.
4. Select the DVR/NVR/camera IP and click forget a password at the right bottom of the software.



1 Step 1: Click Export to download the key request file (XML file) or take a photo of the QR code. Send the XML file or QR code photo to our technical engineers.

Export



2 Step 2: Input the key or import the key file received from the technical engineer to reset the password for the device.

Input Key Import File

New Password:

Confirm Password:

Reset Network Cameras' Passwords

Confirm Cancel

5. Click export and select the path to export a file. Please don't change the file's name.
6. XML file will be saved on your PC